



# **Quick Start Guide**

#### **Getting to Know Your EL-SIE Logger**





# **Install the Batteries**

2 x AAA Batteries: The unit is powered when the batteries are installed. Use AAA 1.5V alkaline batteries only, these are user replaceable.

Loosen the screws and remove the end cap, then fit the batteries in the orientation shown on the label. Replace the end cap and tighten the screws carefully until secure.

## **Connect to your PC or Mac**

All the software needed to configure your EL-SIE, view and analyse the data it logs, is contained within the product itself.

- 1. Connect the logger to your computer using the USB cable supplied
- 2. Open your web browser and into the address bar type  $\ensuremath{\mathsf{http://EasyLog.local}}$
- 3. The EL-SIE home page will load save it to your Favourites or Bookmarks
- 4. Follow the on-screen instructions to configure and start logging
- 5. Disconnect the logger and position it where you want to take readings

Once the logger is running you can plug it back into your computer and, without having to stop it logging, view the data recorded so far. Just select http://EasyLog.local from your Favourites and click on View/Save Data.



## EasyLog Cloud Data Storage

Store your data securely, and make it available from any internet-connected computer or mobile device, with EasyLog Cloud. The EL-SIE can send logged data to the Cloud from your computer or Mac, making sharing and analysis easier

than ever. For more information and to set up an account on EasyLog Cloud, visit www.easylogcloud.com.





Lascar offers a Traceable Calibration Certificate Service on Temperature Data Loggers. Using reference equipment which has been calibrated by a UKAS/NIST/CNAS accredited laboratory and using apparatus traceable to national or international standards. For more information please see **www.lascarelectronics.com**.

Display Inf	ormation		Calibration — CAL MIN MAX (III) — Battery level					
Display	Logger Status	Explanation	Reading —					
U56	USB Connected	The logger is connected via the USB cable	CH - B A BRANK - Alarm status					
	Push to Start	The logger is set up for Push to Start logging, a	Display	Logger Status	Explanation			
PUSH		long press of either button will start logging	Stop	Logger Running	The logger is still logging but can be stopped by a			
	Delayed Start	The logger is set up for Delayed Start logging and will automatically start logging at the specified time			long press of the bottom button			
dLĭ			$\bigtriangleup$	Alarm Triggered	An alarm is currently active on the logger			
	Triggered Start	The logger is set up for Triggered Start logging and will start logging as soon as the specified lim- it (either temperature,	Ĵ	Cumulative Alarm	A cumulative alarm is active on the channel currently being displayed			
1	Low Battery	humidity or pressure) is reached The batteries are low and		High Alarm	A high alarm is active on the channel currently being displayed			
6822 LOW	Warning	should be changed when possible		Low Alarm	A low alarm is active on the channel currently			
FULL	Memory Full Warning	The memory is full and logging has stopped		Held High Alarm	being displayed A high alarm is being held			
<u> </u>	1 <u>6</u> M				on the channel currently being displayed			
	Memory 90% Warning	The memory is 90% full, and data should be downloaded when possible		Held Low Alarm	A low alarm is being held on the channel currently being displayed			
••••••••••••••••••••••••••••••••••••••	Calibration Pending Warning	The calibration will expire in < 30 days on the date shown (can be DD/MM/ YYYY or MM/DD/YYYY)		High Pre-alarm	A high pre-alarm is active on the channel currently being displayed			
	Calibration Expired Warning	The calibration has expired on the date shown (can be DD/MM/ YYYY or MM/DD/YYYY)	$\overset{\sim}{\searrow}$	Low Pre-alarm	A low pre-alarm is active on the channel currently being displayed			

#### **Status LEDs and Sounder**

LEDs	Sounder	Status	LEDs	Sounder	Status
Flashing	Off	Logger primed but not yet logging / Pre-alarm / Memory 90% Full / Calibration Pending (check display for	Flashing	Active	Alarm / Memory Full / Calibration Expired
		specific warning)		Off	Battery Low
Flashing	Off	Logger in operation, no alarms or warnings	Slow Flash		

## **Button Functions**

Screen	Button	Press	Function	Event Recorded
USB	n/a	n/a	n/a	n/a
Push to Start	Any	Long	Start logging	n/a
Triggered Start	n/a	n/a	n/a	n/a
Delayed Start	n/a	n/a	n/a	n/a
Channel – Current reading	Тор	Short	Move to next channel or STOP LOG	n/a
		Long	Clear alarm hold for all channels	Clear Held Alarms
	Bottom	Short	Show Min reading for this channel	n/a
		Long	Mute alarm sounder	Mute Alarm
Channel – Min reading	Тор	Short	Show Min reading for next channel or STOP LOG	n/a
		Long	Reset Max/Min reading for all channels	Clear Max/Min
	Bottom	Short	Show Max reading for this channel	n/a
		Long	Mute alarm sounder	Mute Alarm
Channel – Max reading	Тор	Short	Show Max reading for next channel or STOP LOG	n/a
		Long	Reset Max/Min reading for all channels	Clear Max/Min
	Bottom	Short	Show current reading for this channel	n/a
		Long	Mute alarm sounder	Mute Alarm
STOP LOG?	Тор	Short	Move to Channel 1 (or Warning Screen), also generates an Audit Mark when cycling back through to Channel 1	Audit Mark
	Bottom	Long	Stop logging, returns to Push to Start	n/a
Warning Screen	Any	Short	Move to next warning or Channel 1	n/a

## **IMPORTANT SAFETY INFORMATION**

#### Repairing or Modifying

UK

T +44 (0) 1794 884567

E sales@lascar.co.uk

Never attempt to repair or modify Lascar products. Dismantling them, other than for the purpose of changing replaceable batteries, may cause damage that is not covered under the warranty. Servicing should only be provided by an authorized supplier.



Disposal and Recycling Information You must dispose of Lascar products in accordance with relevant laws and regulations. They contain electronic

from household waste.

HK 52 2389 6502

T +852 2389 6502 E sales@lascar.com.hk USA T +1 (814) 835-0621 E us-sales@lascarelectronics.com

components and therefore must be disposed of separately



www.lascarelectronics.com/data-loggers Iss 1\_10-2019 Disclaimer:

Every effort has been made to ensure the accuracy of this publication and no responsibility or liability can be accepted by Lascar Electronics Limited for any errors or omissions in the content of this document. Data and legislation may change, and so we strongly advise you to obtain and review the most recently issued regulations, standards, and guidelines. This publication does not form the basis of a contract.